

# How to measure for Outdoor Blinds



What you'll need:



Pen/Pencil



Paper




Measuring tape

## Inside (reveal) fit

Inside /reveal fitted blinds are mounted inside the window opening.

Measure and use the "tight" measurement for width and drop. Use a metal tape. The factory will make minor deductions required to allow for fitting into the opening.

**Measure in 3 places** for both the width and the drop, use the smallest measurements.



## Face (outside) fit

Outside fit blinds are mounted outside the window opening.

Measure the size of the recess, then add a little extra on all sides to ensure adequate coverage. No deductions will be taken off the measurements provided.

